

## Series 250-T / Series 2000

### Screen Clip Installation Instructions

#### Installation:

**Step #1** – Insert the clip into the t-slot groove as shown in Figure #1 (weather stripping was not shown in t-slot to improve clarity).

**Step #2** – Rotate screen clip as shown in Figure #2.

**Step #3** – As you continue rotating the screen clip it will snap into place as shown in Figure #3.

**DO NOT SLIDE SCREEN CLIP ON THE EXTRUSION!** Sliding of the screen clip may damage the finish of the window.

#### Recommended Locations (locations may need to be adjusted per screen configuration and size):

**Awning Windows** – 1 clip centered on each jamb and 2 clips at head 6” from the ends.

**Casement Windows** – 1 clip centered on each jamb and 2 clips at head 6” from the ends.

**Hopper Windows** – 2 clips at head 6” from the ends and 2 clips at sill 6” from the ends.

(2 additional screen clips provided for large screen configurations)

**Figure #1**



**Figure #2**



**Figure #3**

