



NARROW STILE 3008

1. CALCULATE EQUAL GLASS SIZES.
2. DIVIDE 2.728 BY 3 FOR ADD AMOUNT OF 0.909.
3. ADD 0.909 TO BOTH O PANELS GLASS.
4. MULTIPLY 0.909 BY 2 FOR ADD AMOUNT OF 1.818.
5. SUBTRACT 1.818 FROM X PANEL GLASS AND SCREEN.

ARCHETYPE NARROW STILE 3005

1. CALCULATE EQUAL GLASS SIZES.
2. DIVIDE 0.844 BY 3 FOR ADD AMOUNT OF 0.281.
3. ADD 0.281 TO BOTH O PANELS GLASS.
4. MULTIPLY 0.281 BY 2 FOR ADD AMOUNT OF 0.562.
5. SUBTRACT 0.562 FROM X PANEL GLASS AND SCREEN.

ARCHETYPE STILE 3767

1. CALCULATE EQUAL GLASS SIZES.
2. DIVIDE 0.894 BY 3 FOR ADD AMOUNT OF 0.298.
3. ADD 0.298. TO BOTH O PANELS GLASS.
4. MULTIPLY 0.298. BY 2 FOR ADD AMOUNT OF 0.596.
5. SUBTRACT 0.596 FROM X PANEL GLASS AND SCREEN.